



# KwiKolumn One Piece Column Wrap

- Finish a column wrap in 50% of the time
- Strong 1 piece construction
- No corner bead
- Minimal cleanup
- Made with  $\frac{5}{8}$ " Fire Code Gypsum (mold resistant available)
- Foam included for 3  $\frac{1}{2}$ " and 4" lally columns
- Stocked in 8' and 10' lengths (special lengths available)

Outside Dimensions: 6  $\frac{1}{4}$ "x6  $\frac{1}{4}$ "x8' or 10' Weight: 3.86lbs/lf (31 lbs/8' – 38.6 lbs/10')

## Tools Needed for Installation:

Caulking Gun – 10 oz PL300 Adhesive (included) – Painter's Tape – Joint Compound & Finishing Tools

## Assembly Instructions

1. Measure floor to ceiling height (see picture below).
2. Mark and cut KwiKolumn to length with saw.
3. Apply  $\frac{1}{4}$ " bead of PL300 adhesive (included) to inside radius of foam pieces. Adhere foam pieces, spaced evenly, to the column. Be sure the pieces are lined up by sliding the Kolumn over the foam, let set for 15 minutes (see picture below).
4. Apply  $\frac{1}{4}$ " bead of PL300 adhesive (included) to outside of foam.
5. Slide column over foam, close open end, tape shut with blue painters tape let set 15 minutes while adhesive sets (see picture below).
6. Mud and tape joint, let dry, sand and paint (see picture below).

**Step 1**



**Step 3**



**Step 5**



**Step 6**



Visit [www.kornerboard.com](http://www.kornerboard.com)

**The Possibilities are Endless**  
Column Wraps, Soffits, Light Coves, Duct Caps,  
Recessed Light Covers and More...

Available at



[www.kamcoboston.com](http://www.kamcoboston.com)